



## Setting Up Hotspot WiFi

### Receiving Your Hotspot


When you receive your **ioWE** hotspot, you will find the following included:

- Hotspot
- Power Supply
- Antenna

Once you've found a suitable location for your hotspot, first connect the antenna to the hotspot. Then plug the power cable in and plug into an outlet near the hotspot placement location. Finally, you'll need to connect the hotspot to WiFi to get up and running. The following section provides a step by step guide on getting connected via the Helium mobile app.

### Connecting to WiFi

The following steps assume you have successfully completed the steps referenced above, and your followed hosted hotspot is shown on the hotspot page of the app as shown below:




Block Time: 75.008 secs • 55,296 Hotspots • C




**Click the name of your hotspot to continue to the hotspot details page.**






**Click the settings gear at the top right, next to the flag.**



**Press the button on your hotspot to initiate Bluetooth pairing mode. Wait a few seconds, then click "Pair".**



**If your hotspot does not show up right away, click "Scan again" until it appears.**

**Once the hotspot shows up, click on its name to proceed.**



**Once you've paired with the hotspot via Bluetooth, select "Wi-Fi Network".**



**Select your Wi-Fi network from the list shown and follow the prompts to enter your Wi-Fi password and complete setup.**

**After successfully completing the setup prompts your hotspot is now connected to Wi-Fi and online! Congratulations!**